



Designed for commercial and industrial use, Adam Equipment's PTS pallet truck scale offers the durability and convenience needed in commercial and industrial settings. PTS facilitates the transport of items from one place to another in warehouses, shipping departments or on production floors. This scale is equipped with steel pallet forks, non-marring polyurethane wheels, and a zero-radius pivoting handle. The display changes color to indicate if the weight is over, under or within preset limits. With a bright LCD that is easily visible in different lighting levels, the PTS offers a wide range of features and functions to provide fast, accurate results.

Expedite warehouse operations and reduce transportation overcharges with the PTS



Features

- Vivid, backlit LCD easily visible in any lighting conditions
- Programmable backlight can be set to "always on," "always off" or "light only when weighing"
- Capacity tracker built into display for easily monitoring possible overloads
- Checkweighing LEDs clearly show under, over and acceptable limits
- Solid non-marring polyurethane wheels
- Colour-coded keys facilitate quick recognition of the most frequently used buttons
- RS-232 interface is available to provide speedy connection to computers and printers
- Splash-proof housing, keypad and display are easy to clean
- Wheels swivel, allowing easy movement
- Audible overload alarm warns when capacity is exceeded
- Checkweighing with audible alarm
- External calibration allows for verification and adjustment with weights
- Parts counting with preset sample sizes
- Auto-clear function enables the last item to be reset each time the scale returns to zero
- Selectable digital filtering for animal/dynamic weighing enables consistent results for moving subjects
- Zero-tracking feature ensures display returns to zero reading
- Rechargeable battery included for operation almost anywhere
- Programmable auto power-off to save energy
- AC adapter included

Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Dynamic / animal weighing

About ADAM:

For more than 40 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Model	PTS 2000
Capacity	2000 kg
Readability	0.5 kg
Repeatability (S.D.)	1kg
Linearity (+/-)	1kg
Fork	160x1150mm
Weighing Units	kg, lb, lb:oz, oz, N, custom unit
Stabilisation Time (sec)	2
Interface	RS-232
Calibration	External calibration
Display	40mm
Power Supply	12VDC 50/60Hz 800mA adapter / Internal rechargeable battery
Operating Temperature	-10° to 40°C
Housing	Mild steel base
Overall Dim.	550x1525x1175mm (wxdxh)
Net Weight	125kg

Accessories

Item number	Description
3102311619	In-use wet cover
700400103	RS-232 cable
3074010507	RS-232 to USB adapter (must order corresponding RS-232 cable)
1120011156	ATP thermal printer
3126011263	ATP thermal printer paper
3126011281	ATP thermal printer paper (pack of 10)
600002028	AdamDU data collection program
700660289	Calibration certificate

Key Accessories



ATP thermal printer
Easy-to-use features combined with quick set-up equals a truly versatile thermal printer. A single push-button feed key and three easy-to-read LED indicators make operation simple.



In-use wet cover
In-use covers provide an easy and affordable way to help keep the balance clean and protected.



AdamDU data collection program
Adam DU software connects a balance to the laboratory network, helping to achieve seamless data collection, transfer and analysis. DU features an easy-to-use interface with a main command window, allowing users to quickly collect information from up to eight Adam balances simultaneously using RS-232 or USB connections.

Supplied by