



With intuitive operation, Latitude compact bench scales deliver excellent value for quick, basic weighing, checkweighing, and counting needs. Latitude scales feature amber, green and red LEDs to indicate if a sample is under, within, or over the preset limits. Latitude is ideal for catering, office, production, warehouse or field use, as it is powered by the included AC adapter or internal rechargeable battery. A fully charged battery operates for an impressive 240 hours, so you don't have to worry about losing power. For added flexibility and convenience, you can also operate the Latitude using any USB power source.

Light weight and portable for multipurpose use



Features

- Vivid, backlit LCD easily visible in any lighting conditions
- Checkweighing LEDs clearly show under, over and acceptable limits
- Overload protection helps prevent damage to internal components
- Rugged construction stands up to industrial use
- Sealed keypad protects against dirt and spills
- Simple key operation allows for easy set up and operation
- Large, grade 304 stainless steel pan allows swift cleaning
- Adjustable leveling feet help optimize setup
- External calibration allows for verification and adjustment with weights
- Checkweighing with audible alarm
- Hold function freezes the displayed weight, allowing time to elapse without losing the result
- Parts counting with preset sample sizes
- Rechargeable battery included for operation almost anywhere
- Programmable auto power-off to save energy
- Battery level is clearly displayed to show the user when the scale needs to be recharged
- Operates with a low voltage USB input providing flexibility for powering the device

Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Display hold

About ADAM:

For more than 45 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Latitude Compact Bench Scales



Model	LBX 3	LBX 6	LBX 12	LBX 30
Capacity	6lb / 3kg	12lb / 6kg	25lb / 12kg	65lb / 30kg
Readability	0.001lb / 0.5g	0.002lb / 1g	0.005lb / 2g	0.01lb / 5g
Repeatability (S.D.)	0.001lb / 0.5g	0.002lb / 1g	0.005lb / 2g	0.01lb / 5g
Linearity (+/-)	0.002lb / 1g	0.004lb / 2g	0.01lb / 4g	0.02lb / 10g
Pan Size	9.6"x7.1" / 245x180mm			
Weighing Units	g, kg, lb, lb:oz, oz			
Stabilization Time (sec)	1			
Calibration	External calibration			
Display	Backlit LCD with 0.9" / 24mm -high digits			
Power Supply	5VDC 1A adapter / Internal rechargeable battery			
Battery Life (Hours)	240			
Operating Temperature	0° to 40°C / 32° to 104°F			
Housing	ABS plastic			
Overall Dim.	10"x11.4"x4.1" / 255x290x105mm (wxdxh)			
Net Weight	5.5lb / 2.5kg			

Accessories

Item number	Description
3022014061.....	In-use wet cover
2020014062.....	In-use cover (pack of 5)
2020014063.....	In-use cover (pack of 10)
303149759.....	Vegetable Scoop (complete with fitting to scales)
303149760.....	Confectionery Scoop (complete with fitting to scales)
303149761.....	Fish Scoop (complete with fitting to scales)
700660290.....	Calibration certificate

Supplied by

www.adamequipment.com

Adam Equipment follows a policy of continuous improvement and reserves the right to change specification and pricing without notice.
Adam Equipment's standard terms and conditions of sale apply. Errors and omissions excepted.
©2018 Adam Equipment. NA-8023 10/30/18